

CAPS

INTERNATIONAL



Step 1. Attach the four (4) legs to the bottom of the support pole. The bolt head and washer should be placed through the pre-drilled hole located at the lower end of the support pole. The washer and nut should be attached to the bottom of the leg. Please be sure to only hand tighten the bolts until all of the bolts have been attached to all of the legs.



Step 2. Loosen the clamp at the top of the support pole. Pull the inner pole up approximately 4 inches and retighten the clamp to hold the inner pole in place.



Step 3. Align the flash head seating bracket with the top of the support pole. Carefully lower the flash head onto the support pole.

Your assembled T-Shirt flash should resemble the picture at left.

FLASH UNIT OPERATION

1. The bottom of the flash head should be approximately two (2) inches from the top of your print work.
2. Turn on the Flash Unit.

PO Box 48188 – Sarasota – FL - 34230
(423) 283-4788 - (800) 330-5515 - (423) 283-4545 Fax
www.caps-screenprinting.com E-Mail: caps@naxs.net

CAPS INTERNATIONAL

FLASH UNIT OPERATION (Continued)

3. Expose the print work for approximately 12 to 13 seconds.
4. As each Flash Cure Unit is unique, you may need to fine tune these steps slightly to achieve the desired results.

WARNING! Leaving the Flash Cure Unit energized over your platen for an extended period will damage and/or warp the platen. Platens are not a warranted item.