

CAPS

INTERNATIONAL

MODEL UV2536 – NO LID – ANALOG TIMER

NOTE: All exposure operations should be done in a reduced light environment to prevent premature exposure of the screen emulsion to outside sources of light contamination.

- 1. Position film positive to the desired position on the screen and center the screen frame on the glass surface.**
- 2. Lay a cover over the screen frame, being sure the entire glass area of the exposure unit is covered as well. The cover should be of a type that will block all external light sources. This will prevent unintentional exposure of your screen imaging area.**
- 3. Set the desired exposure time with the round knob on the analog timer. Go past the desired time on the analog timer, and then move the dial back to the desired time. The recommended exposure times are two (2) minutes with one step emulsion and four (4) minutes with two step or dual cure emulsion. These recommended times may have to be adjusted to fit the needs of your unit, emulsion, or art work. This procedure is totally “trial and error.”**
- 4. When the exposure process is finished, the analog timer will turn off the exposure unit. Remove the cover and then remove the exposed screen and film positive.**

P O Box 48188, Sarasota, FL 34230
(423) 283-4788 (800) 330-5515 (423) 283-4545 Fax
www.caps-screenprinting.com E-Mail: caps@naxs.net